

Use the following tables when reading debugs and the associated values within the debugs.

Guide Contents
Troubleshooting Cisco IOS Voice Overview
Debug Command Output on Cisco IOS Voice Gateways
Filtering Troubleshooting Output
Cisco VoIP Internal Error Codes
Troubleshooting Cisco IOS Voice Telephony
Troubleshooting Cisco IOS Voice Protocols
Troubleshooting Cisco IOS Telephony Applications
Monitoring the Cisco IOS Voice Network
Cause Codes and Debug Values

Contents

- [1 Q.931 Call Disconnection Causes](#)
- [2 Codec Negotiation Values](#)
- [3 Tone Types](#)
- [4 FAX-Rate and VAD Capabilities Values](#)

Q.931 Call Disconnection Causes

These are cause codes from the **debug voip ccapi inout** command.

Call Disconnection Cause Value (in Hex)	Meaning and Number (in Decimal)
CC_CAUSE_UANUM = 0x1	Unassigned number (1)
CC_CAUSE_NO_ROUTE = 0x3	No route to destination (3)
CC_CAUSE_NORM = 0x10	Normal call clearing (16)
CC_CAUSE_BUSY = 0x11	User busy (17)
CC_CAUSE_NORS = 0x12	No user response (18)
CC_CAUSE_NOAN = 0x13	No user answer (19)
CC_CAUSE_REJECT = 0x15	Call rejected (21)
CC_CAUSE_INVALID_NUMBER = 0x1C	Invalid number (28)
CC_CAUSE_UNSP = 0x1F	Normal, unspecified (31)
CC_CAUSE_NO_CIRCUIT = 0x22	No circuit (34)
CC_CAUSE_NO_REQ_CIRCUIT = 0x2C	No requested circuit (44)
CC_CAUSE_NO_RESOURCE = 0x2F	No resource (47)
CC_CAUSE_NOSV = 0x3F	Service or option not available, or unspecified (63)

Codec Negotiation Values

These codec negotiation values are from the **debug voip ccapi inout** command.

Negotiation Value	Meaning
codec=0x00000001	G711 ULAW 64K PCM
codec=0x00000002	G711 ALAW 64K PCM
codec=0x00000004	G729

codec=0x00000004	G729IETF
codec=0x00000008	G729a
codec=0x00000010	G726r16
codec=0x00000020	G726r24
codec=0x00000040	G726r32
codec=0x00000080	G728
codec=0x00000100	G723r63
codec=0x00000200	G723r53
codec=0x00000400	GSMFR
codec=0x00000800	G729b
codec=0x00001000	G729ab
codec=0x00002000	G723ar63
codec=0x00004000	G723ar53
codec=0x00008000	CLEAR_CHANNEL

Tone Types

Tone Types	Meaning
CC_TONE_RINGBACK 0x1	Ring tone
CC_TONE_FAX 0x2	Fax tone
CC_TONE_BUSY 0x4	Busy tone
CC_TONE_DIALTONE 0x8	Dial tone
CC_TONE_OOS 0x10	Out of service tone
CC_TONE_ADDR_ACK 0x20	Address acknowledgement tone
CC_TONE_DISCONNECT 0x40	Disconnect tone
CC_TONE_OFF_HOOK_NOTICE 0x80	Tone indicating that the phone is off-hook
CC_TONE_OFF_HOOK_ALERT 0x100	A more urgent version of CC_TONE_OFF_HOOK_NOTICE
CC_TONE_CUSTOM 0x200	Custom tone-used when you are specifying a custom tone
CC_TONE_NULL 0x0	Null tone

FAX-Rate and VAD Capabilities Values

Values	Meaning
CC_CAP_FAX_NONE 0x1	Fax disabled or not available
CC_CAP_FAX_VOICE 0x2	Voice call
CC_CAP_FAX_144 0x4	14,400 baud
CC_CAP_FAX_96 0x8	9,600 baud
CC_CAP_FAX_72 0x10	7,200 baud
CC_CAP_FAX_48 0x20	4,800 baud
CC_CAP_FAX_24 0x40	2,400 baud
CC_CAP_VAD_OFF 0x1	VAD disabled
CC_CAP_VAD_ON 0x2	VAD enabled