

This chapter contains the following troubleshooting topics:

- [About Troubleshooting the System](#)
- [About Troubleshooting T1 CAS, T1 PRI, and E1 Systems](#)
- [About Troubleshooting IP Ports That Do Not Answer](#)
- [About Troubleshooting IP Calls That Connect but No Audio is Heard](#)
- [About Troubleshooting When You Cannot Outdial on IP Ports](#)
- [About Troubleshooting Audio Server and Web Conferencing Licensing Issues](#)

For details on troubleshooting the various Cisco Unified MeetingPlace gateways, see the administration guide for the specific gateway.

Note: For more information about the CLI commands referenced in this chapter, see [Command-Line Interface Reference](#).