

**Main page:** [Cisco Unified MeetingPlace, Release 7.0](#)

**Up one level:** [Reference Information](#)

To find this page, click **System Configuration > Call Configuration > Auto Attend Translation Configuration > Add New**.

**Table: Field Reference: Add Translation Rule Page and Edit Translation Rule Page**

Field	Description
Description	<p>Enter information to help you and other system administrators understand the translation rule.</p> <p>Example: Converts a 7-digit number to a 5-digit extension.</p>
Digits to match	<p>Number of digits that must be in the incoming ANI (ANI = automatic number ID, or the phone number from which the user called) in order for this rule to be applied.</p> <p>Example: Suppose this field is set to 5:</p> <ul style="list-style-type: none"> <li>• If the ANI is 50123, then the system applies this rule.</li> <li>• If the ANI is 0123 or 5550123, then the system does not apply this rule.</li> </ul> <p>Recommendation: The ANI can vary depending on whether calls are received from internal, external, long distance, or international sources. Use a large enough value to preserve uniqueness for ANI matches. We recommend a value of 4 or 5.</p> <p>Restriction: You cannot modify the preconfigured translation rule, in which this field is set to 0. The system uses the preconfigured translation rule to find a user profile phone number that matches the incoming ANI exactly without adding or deleting any digits.</p>
Match string	<p>Apply this rule if this string matches the beginning of the ANI digits.</p> <p>This string is removed from the ANI.</p> <p>Example: If this field is set to 555, and the ANI is 5550123, remove the 555 to make the modified ANI equal to 0123.</p>
Replace by	<p>Insert these digits at the beginning of the ANI.</p> <p>Example: If this field is set to 5 and the ANI is 0123, then the ANI becomes 50123.</p>

**Related Topics**

- [Configuring the Auto Attend Feature for Cisco Unified MeetingPlace](#)
- [Auto Attend Translation Configuration Page](#)