

Main page: [Cisco Unified MeetingPlace, Release 7.0](#)

Up one level: [Reference Information](#)

Use this page to define Automatic Number Identification (ANI) translation rules for the auto attend feature. These translation rules enable the system to match different ANI formats to the phone numbers in user profiles.

To find this page, click **System Configuration > Call Configuration > Auto Attend Translation Configuration**.

Table: Navigation Reference: Auto Attend Translation Configuration Page

To	Do This
Sort by number of digits to match, string to match, or string to replace with	Click the Digits to match , Match string , or Replace by column heading.
Change the alphanumeric sort order to ascending or descending	Click the column heading to change the arrow direction: <ul style="list-style-type: none"> • Down arrow-ascending sort • Up arrow-descending sort
Display a shorter or longer list of auto attend translation rules in one view	At the bottom of the page, in the Rows per page field, select the number of entries to display.
Display a different page of auto attend translation rules	At the bottom of the page, perform one of the following actions: <ul style="list-style-type: none"> • In the Go field, enter the page number to display, and click Go. • Click the arrows to page through the list.
Edit an existing auto attend translation rule	Click edit in the same row as the auto attend translation rule.
Create a new auto attend translation rule	Click Add New .
Delete one or more auto attend translation rule	Check the appropriate check boxes in the far left column, then click Delete Selected . Restriction: You cannot delete the preconfigured translation rule, in which the <u>Digits to match</u> field is set to 0. The check box is dimmed for the preconfigured auto attend translation rule.

Related Topics

- [Configuring the Auto Attend Feature for Cisco Unified MeetingPlace](#)
- [Add Translation Rule Page](#)