

This chapter provides disconnect (DISC) commands for the Cisco ONS 15454 SDH and Cisco ONS 15600 SDH.

Contents

- 1
 - DISC-TACC
 - ◆ 1.1
 - Usage
 - Guidelines
 - ◆ 1.2
 - Category
 - ◆ 1.3
 - Security
 - ◆ 1.4
 - Input
 - Format
 - ◆ 1.5
 - Input
 - Example
 - ◆ 1.6
 - Input
 - Parameters

DISC-TACC

The Disconnect Test Access (DISC-TACC) command disconnects the TAP and puts the connection back to its original state (no splits). For more information on TACC, refer to the *Cisco ONS SDH* and *Cisco ONS 15600 SDH TL1 Reference Guide*.

Usage Guidelines

For this command to be applicable, you must first create the TAP using the ED-<VC_PATH> or ED-VC12 command.

The following actions will return error messages:

- If you send this command to an already disconnected connection, a SADC error message is returned.
- If the system cannot release TAP, an SRTN error message is returned.

Note: If the test access connection is intrusive, the original state of the facility/path is restored after this command is executed. Test access connections are dropped automatically if the TL1 session is terminated or is timed out.

Category

Troubleshooting and Test Access

Security

Maintenance

Input Format

DISC-TACC:[<TID>]:<TAP>:<CTAG>;

Input Example

DISC-TACC:CISCO:8:123;

Input Parameters

<TAP>	<p>The test access path number. The TAP number must be an integer with a range of 1 to 999. TAP is a string.</p> <p>Note: This command only supports disconnecting one TAP at a time.</p>
-------	--