

This chapter provides disconnect (DISC) commands for the Cisco ONS 15454 SDH and Cisco ONS 15600 SDH.

## Contents

- 1
  - DISC-TACC
    - ◆ 1.1
      - Usage
      - Guidelines
    - ◆ 1.2
      - Category
    - ◆ 1.3
      - Security
    - ◆ 1.4
      - Input
      - Format
    - ◆ 1.5
      - Input
      - Example
    - ◆ 1.6
      - Input
      - Parameters

## DISC-TACC

The Disconnect Test Access (DISC-TACC) command disconnects the TAP and puts the connection back to its original state (no splits). For more information on TACC, refer to the *Cisco ONS SDH* and *Cisco ONS 15600 SDH TL1 Reference Guide*.

### Usage Guidelines

For this command to be applicable, you must first create the TAP using the ED-<VC\_PATH> or ED-VC12 command.

The following actions will return error messages:

- If you send this command to an already disconnected connection, a SADC error message is returned.
- If the system cannot release TAP, an SRTN error message is returned.

**Note:** If the test access connection is intrusive, the original state of the facility/path is restored after this command is executed. Test access connections are dropped automatically if the TL1 session is terminated or is timed out.

### Category

Troubleshooting and Test Access

### Security

Maintenance

### Input Format

DISC-TACC:[<TID>]:<TAP>:<CTAG>;

### Input Example

DISC-TACC:CISCO:8:123;

### Input Parameters

<TAP>	<p>The test access path number. The TAP number must be an integer with a range of 1 to 999. TAP is a string.</p> <p><b>Note:</b> This command only supports disconnecting one TAP at a time.</p>
-------	--